The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd., reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

Accessories Precautions

The GPS antenna is located in the dashboard. Metallic front or side window tinting can seriously degrade or obstruct GPS reception.

Signal noise from devices such as radar detectors, vehicle tracking devices, remote starters, and additional amplifiers can disrupt the navigation system. If you install any such item, install it away from the navigation display and antenna.

Important Safety Information

⚠ WARNING

Using the navigation system while driving can take your attention away from the road, causing a crash in which you could be seriously injured or killed.

Only operate system controls when the conditions permit you to safely do so.

Avoid focusing on the screen or manually operating the system controls while driving.

Certain on-screen controls are disabled when driving, but most of the audible instructions and voice commands continue to function. Pull to the side of the road if you need to devote more attention and time to look at the screen or access additional menus.

Route guidance may conflict with street closures, road construction, detours, and out-of-date map data.

The system itself may also have limitations. Verify route information by carefully observing roads, signs, and signals. Always use your own judgment and obey traffic laws.

➲ **System Limitations** P. 127

NOTICE

Clean the screen with a soft, damp cloth. You may use a mild cleaner intended for use on navigation screens.

Contents

System Setup P. 15

Start-up 16
Personal Information 17
Display Mode Settings 26
Map & Vehicle 28
Navigation 36
Traffic 45
Other Settings 46
Data Reset 54

Navigation P. 55

Entering a Destination 56
Calculating the Route 72
Driving to Your Destination 75
Map Operation 79
Changing Your Route 88
Changing Your Destination 95

Other Features P. 103

About Apps Menu 104
ecoRoute™ 105
Information Functions 113

Troubleshooting P. 119

Troubleshooting 120

Reference Information P. 125

System Initialization 126
System Limitations 127
Customer Assistance 129
Legal Information 130

Quick Reference Guide P. 2
System Setup P. 15
Navigation P. 55
Other Features P. 103
Troubleshooting P. 119
Reference Information P. 125
Index P. 133

Overview—Functions at a Glance

Navigation

You can select any place/landmark as a destination by using the touch screen. The navigation system gives you turn-by-turn driving directions to your destination.

Store home address P. 18
Register *1* home address.

Store contacts P. 20
Store locations to use as the destination.

Enter destination P. 56
Select your destination using *9* methods.

Select route P. 73
Set route preferences and select one of different routes.

Track route P. 75
Follow your route in real-time with voice guidance.

Traffic Information* P. 84
View and avoid congestion and traffic incidents.
*: Available only in certain areas.

Avoid certain areas P. 39
Set streets and areas to detour around.

Add waypoints P. 90
Add “pit stops” along your route.

HOME Screen

The system displays various functions from the HOME screen. Select **HOME** at any time to return to the main HOME screen.

(Power)
Select and hold the button for about ten seconds to reboot the system.

HOME
Display the HOME screen.
VOL (Volume)
Increase or decrease audio volume.
MENU
Display the menu screen of each function (this is not used in the navigation app).
BACK
Go back to the previous screen.

Navigation
Display the map screen and operate the navigation app.

(Display Mode)
Switch between Day and Night mode manually.

App/Widget List
Display the **App/Widget List**. You can also display the navigation menu screen to select from the **App/Widget List**.

Navigation app

Navigation Menu Screen

Display the map screen and operate the navigation features.

GPS signal strength P. 117
Display the satellites status.

Where To? P. 56
Select search methods to enter a destination for route guidance.

Apps P. 104
Display the useful functions incorporated into the navigation app.



View Map P. 6
Display the map screen.

Settings P. 15
Change settings for navigation functions.

Touchscreen Operation

You can operate the system using your finger on the touchscreen.
The touchscreen can be operated if you are wearing thin gloves, but it may be more difficult for the system to respond.

Tap

Touch the screen lightly with your finger to select an item on the screen.

Flick

Lightly sweep your finger side to side or up and down to scroll a list or map.

Slide

Move your finger slowly across the screen to scroll the map.

Pinch In/Out

Open or close your fingers on the screen in a pinching motion to zoom in or out of the map.



How to Enter Information

You can enter information (e.g., town names, street names, numbers, and symbols) when prompted on input screens by a different method.

Using the Touchscreen

Select a character or icon on the screen to select it.

- Select to remove the last entered character.
- Select to remove all entered characters.
- Select to display upper/lower case characters.
- Select to enter a space character.
- Select &7% to display other types of characters.
- Select to change the keypad type. You can enter a character with flick input as well.

On input search screens, the suggested search terms are displayed. Select to display a list of possible entries.

Help

This navigation app comes with help information, which tells you how to use this navigation. P. 113

1. Press the **HOME** button and then select **Navigation**.
2. Select **Apps**.
3. Select **Help**.
4. Select a help topic.

- Select to search help topics by keyword.
- You can also display a help topic to select on each menu screen.

Map Screen Legend

The colour of the map is different depending on the selected language.



During Route Guidance

During route guidance, route information is displayed on the map screen.
You can see the detailed information on the turn information screen.

Map Screen

Guidance Screen



Day or Night Mode

Press the (Display mode) button to manually switch between Day and Night mode.



Navigation—Home Addresses and Going Home

The "Home" feature automatically routes you to your home address from any location simply by selecting **Go Home**. You can store one home address. P. 18

The order of the steps may change depending on the map data loaded on your device.

Storing Your Home Address

1. Press the **HOME** button and then select **Navigation**.
2. Select **Where To?**.
3. Press ☰ and then select **Set Home Location**.



4. Select **Enter My Address**.



5. Select **Search All**.

6. Enter a house number and then select **Done**.

7. Enter a street and then select **Done**.

8. Select a street from the list.



If the select Town screen is displayed, select a town.

9. Select an address from the list.
10. Select **Select**.

Going Home

1. Press the **HOME** button and then select **Navigation**.
2. Select **Where To?**.
3. Select **Go Home**.

Navigation—Entering a Destination

Enter your destination using one of several methods, then follow route guidance on the map to your destination.
The order of the steps may change depending on the map data loaded on your device.

1. Press the **HOME** button and then select **Navigation**.
2. Select **Where To?**.

3. Select **Address**.

4. Select **Search All**.

5. Enter the house number and select **Done** if necessary.

6. Enter the name of your destination street and select **Done**.

7. Select your destination street from the list.



If the select Town screen is displayed, select a town.

8. Select an address from the list.

9. Select **Go!**.
   Route guidance to the destination begins.



- **Routes**: Choose one of multiple routes.



- : Display your destination map and save a place.

Navigation—Changing Route or Destination

You can alter your route by adding waypoints to visit, adding streets to avoid, or changing your destination during route guidance.

Adding a Waypoint (“Pit Stop”)

You can add waypoints along your route.
P. 90

1. Press the **HOME** button and then select **Navigation**.
2. Select **Where To?**.
3. Select search method.
4. Select the location to add to the destination list and select **Go!**.
5. Select **Add to Active Route**.
6. If necessary, edit the order of the destinations and select **Done**.



Changing Your Destination

There are three methods you can use to specify a new destination during route guidance.

- Searching nearby hospitals, police stations, or fuel stations P. 96
  Select the vehicle icon and select an item.
- Selecting an icon on the map P. 95
  Select a place/landmark icon or a new area on the map twice.
- Entering a new destination P. 98
  Select **Where to?** and then enter a new destination.

Canceling Your Route

1. Press the **HOME** button and then select **Navigation**.
2. Select **View Map**.
3. Select .

Troubleshooting

For more Information P. 119

Q Why does the vehicle position icon on the map appear slightly off my actual position, especially at intersections?

A This is normal. The navigation system is unaware of the width of intersections. Large differences in vehicle position can indicate a temporary loss of the GPS signal.

Q Why does the "arrival time" display sometimes increase even though I am getting closer to my destination?

A The "arrival time" is based on the speed limit on each road. Depending on the traffic conditions, the "arrival time" may be calculated to be earlier or later.

Q Why does my clock frequently change the time forward and backward by one hour?

A The clock setting is automatically updated based on your GPS location.

➔ **Current** P. 47

Q How do I turn on the navigation system voice guidance?

A
1. Press the **HOME** button and then select **Settings**. Select **System**, and then select **Sound/Beep** tab. Check that **Volume** is not set to 0.
2. Press the **HOME** button. Select **Navigation** > **Settings** > **Navigation**. Check that **Voice Prompts** is not set to off.

Q My battery was disconnected or went dead, and the navigation system is asking for a code. Where do I find it?

A In most cases, you do not need to enter a code. Simply press and hold the ⏻ (Audio Power) button for two seconds; the system should reactivate.

➔ **System Initialization** P. 126

Q How do I specify a destination when an entered town or street could not be found?

A Try selecting the destination directly from the map.

How to Use This Manual

This section explains different methods on how you can easily find information in this manual.

Searching the Table of Contents

P. 1

Two types of Tables of Contents help you find your desired information.



Table of Contents

First, find the general chapter related to what you are looking for (e.g., entering a destination from the Favourites). Then, go to that chapter to view a more specific table of contents.

Chapter Contents

This more detailed table of contents shows you exactly what information is listed by section and title.

Searching the Index

P. 133

Menu items displayed on the navigation screen (e.g., **Favourites**) can be found individually in the Index.



Navigation Screen

Index

The Index consists of main terms and sub-entries. The sub-entries help you get to the desired page depending on what you are looking for.

Go to the Next Page



After following the menu tree, step-by-step instructions explain how to achieve the desired result.

Menu Tree

The menu tree helps guide you through the system's menu options. To get to your desired function, follow the menu tree in order of the steps shown.

HOME ▶ Navigation ▶ Where To? ▶ Favourites

Select the item on the system control panel.

Select **HOME**.

Select the menu option.

Select **Favourites**.

* Sample pages and images in this section may differ from the actual ones.

System Setup

This section describes the start-up procedure and the navigation and setup functions.

Start-up 16
Personal Information 17
Setting Home Location 18
Deleting Shortcuts 19
Favourites Locations 20
Display Mode Settings 26
Switching Display Mode Manually 26
Map & Vehicle 28
Vehicle 29
Driving Map View (Map Orientation) 30
Map Detail 31
Map Theme 32
Map Buttons 33
Map Layers 34
Dashboards 34
myMaps 35
Navigation 36
Calculation Mode 37
Avoidances 38
Custom Avoidances 39
Traffic 45
Other Settings 46
Units & Time 46
Language & Keyboard 49
Device 52
Data Reset 54
Reset Factory Default Settings 54

The navigation system starts automatically when you turn the ignition switch* to ACCESSORY or ON. At start-up, the following Confirmation screen is displayed.



1. Select **OK**.
- ▶ The HOME screen is displayed.
- ▶ If you do not select **OK**, the screen will become completely black after 30 seconds.



2. Select **Navigation**.

3. Select **Agree**.

Start-up

Avoid focusing on the screen and drive safely following the actual traffic restrictions.

If the navigation system loses power at any time, you may need to press and hold the ⏻ (Audio Power) button for more than two seconds, or you may be prompted for the 5-digit security code.

System Initialization P. 126

You can also start the navigation app by selecting ⋯ on the HOME screen.

HOME Screen P. 3

When you use the navigation app, the system may close other apps.

* Models with the keyless access system have an **ENGINE START/STOP** button instead of an ignition switch.

HOME ▶ Navigation ▶ Where To?

Use the personal information menu to set your home location. You can also delete unwanted shortcuts.

1. Select ☰.
▶ The menu screen is displayed.
2. Select an item.

The following items are available:

- **Set Home Location**: Sets your home location.
  Setting Home Location P. 18
- **Remove Shortcut(s)**: Deletes shortcuts.
  Deleting Shortcuts P. 19

Setting Home Location

HOME ▶ Navigation ▶ Where To? ▶ ☰ ▶ Set Home Location



Select an item.

The following items are available:

- **Enter My Address**: Sets the home location by entering the address.
  Storing Your Home Address P. 8
- **Use My Current Location**: Sets your current location as your home location.
- **Choose from Recently Found**: Sets the home location from a recently found location.

Deleting Shortcuts

HOME ▶ Navigation ▶ Where To? ▶ ☰ ▶ Remove Shortcut(s)

1. Select a shortcut with the ⓧ if you want to delete.

2. Select a shortcut again.
3. Select **Save**.

Favourites Locations

You can save locations so you can quickly find them and create routes to them.

■ Saving a Favourite Location

1. Display the screen where the location of the destination can be confirmed.

➡ **Entering a Destination** P. 56

2. Select ☰.
3. Select **Save**.
4. Select **OK**.

Saving Your Current Location

HOME ▶ Navigation ▶ View Map



1. Select the vehicle icon.
2. Select **Save**.



3. Enter a name of the location.
4. Select **Done**.
5. Select **OK**.

Continued

■ Editing a Favourite Location

HOME ▶ Navigation ▶ Where To? ▶ Favourites



1. Select a saved location you want to edit.
2. Select .



3. Select .
4. Select **Edit**.



5. Select an item.

The following items are available:

- **Name**: Enters a new name for the location.
- **Phone Number**: Enters a phone number.
- **Categories**: Creates or changes the category in which this location is saved.
- **Change Map Symbol**: Select a new symbol.

Continued

■ Deleting a Favourite Location

HOME ▶ Navigation ▶ Where To? ▶ Favourites



1. Select a saved location you want to delete.
2. Select .



3. Select .
4. Select **Delete**.
5. Select **Yes**.

Deleting Favourites Locations

HOME ▶ Navigation ▶ Where To? ▶ Favourites

1. Select ☰.
2. Select **Delete Favourite(s)**.



3. Select a saved location you want to delete.
   ▶ Select **Select All** to delete all saved locations.
4. Select **Delete**.
5. Select **Yes**.

Switching Display Mode Manually

Set the screen brightness separately for Day and Night modes. Press the (Display mode) button to cycle through the display modes (Day to Night to Off).

Press the (Display mode) button.

▶ The Brightness bar is displayed for a few seconds.

▶ Select + or − to adjust the brightness.

Switching Display Mode Manually

You can also adjust the display brightness by sliding or flicking on the bar.

Illumination control	Priority	Operation
[☼☽] button	1	Selects Day or Night display mode when the user wants to change the brightness of the display temporarily. **Remember:** This button overrides all other display brightness adjustment that is set by the sunlight sensor automatically or you changed manually from the System settings screen.
Sunlight sensor* (see your Owner's Manual for location)	2	If the sunlight sensor detects daylight and the headlights are turned on, the system automatically overrides the Night display and displays the Day display mode. **Remember:** If desired, use the [☼☽] button to override this automatic choice.
Dash illumination adjustment buttons (see your Owner's Manual for location)	3	When the headlights are turned on, and you wish to have the Day display mode, adjust the illumination to the full brightness (beeps). **Remember:** Adjust the dash brightness back to midrange to allow auto switching by sensing the headlights are on or off.
Headlights (Auto*/On/Off)	4	When turned on, the display changes to Night display mode. The previous three controls listed above can "cancel" this function. **Remember:** Use the [☼☽] button, or adjust the dash illumination to full brightness, to set the display to your desired choice.

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle

Change the map settings.



Select an item.

The following items are available:

- Vehicle: Changes the icon to represent your position on the map.
  Vehicle P. 29
- Driving Map View: Sets the perspective on the map.
  Driving Map View (Map Orientation) P. 30
- Map Detail: Sets the level of detail on the map. More detail may cause the map to draw slower.
  Map Detail P. 31
- Map Theme: Changes the colour of the map data.
  Map Theme P. 32
- Map Buttons: Sets which icons are included on the map. Up to three icons can be included on the map.
  Map Buttons P. 33
- Map Layers: Sets the data that appears on the map.
  Map Layers P. 34
- Dashboards: Sets the map dashboard layout.
  Dashboards P. 34

- **Auto Zoom**: Sets whether to the auto zoom on the map screen.
- **myMaps**: Sets which installed maps the device uses.
  ➡ **myMaps** P. 35

Vehicle

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Vehicle

You can choose your vehicle icon.

1. Select an option.
2. Select **Save**.

Driving Map View (Map Orientation)

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Driving Map View

Select the map orientation.



1. Select an option.
2. Select **Save**.

The following options are available:

- **Track Up**: Displays the map with your direction of travel facing upwards.
- **North Up**: Displays the map with North always pointing up.
- **3-D** (factory default): Displays the map in 3D with your direction of travel facing upwards.

Map Detail

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Map Detail

Sets the level of detail on the map.



1. Select an option.
2. Select **Save**.

The following options are available:

- **More**: Sets the level of detail shown on the map to most.
- **Normal** (factory default): Sets the level of detail shown on the map to normal.
- **Less**: Sets the level of detail shown on the map to least.

Map Theme

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Map Theme

Changes the colour of the map data.



1. Select an option.
2. Select **Save**.

Map Buttons

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Map Buttons

Sets the shortcuts that appear in the map tools menu.



1. Select if you want to delete and then select **OK**.
2. Select to add new shortcut.



3. Select an option.
4. Select **Save**.

Map Buttons

Reset to Defaults
Resets the settings to the factory defaults.

Map Layers

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Map Layers

Sets the data that appears on the map screen.



1. Select an option.
2. Select **Save**.

Dashboards

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ Dashboards

Switches the dashboard layout.

1. Select ◇ or ◇.
2. Select **Save**.

myMaps

HOME ▶ Navigation ▶ Settings ▶ Map & Vehicle ▶ myMaps

Select an option.

HOME ▶ Navigation ▶ Settings ▶ Navigation

Change the navigation settings.



The following items are available:

- **Calculation Mode**: Sets route preference.
  Calculation Mode P. 37
- **Avoidances**: Sets road features to avoid on a route.
  Avoidances P. 38
- **Custom Avoidances**: Allows you to avoid specific roads or areas.
  Custom Avoidances P. 39
- **Advanced Detours**: Sets the length of the detour.
- **Safe Mode**: Sets the operation limit while driving.
- **Voice Prompts**: Turns the voice prompts on or off.
- **GPS Simulator**: Stops the device from receiving a GPS signal.

Navigation

Safe Mode and **GPS Simulator** are set to off as factory default.

Calculation Mode

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Calculation Mode

Sets the data that appears on the map screen.



1. Select an option.
2. Select **Save**.

The following items are available:

- **Faster Time** (factory default): Calculates routes that are faster to drive but can be longer in distance.
- **Shorter Distance**: Calculates routes that are shorter in distance but can take more time to drive.
- **Less Fuel**: Calculates routes that could use less fuel than other routes.

Avoidances

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Avoidances



1. Select an option.
2. Select **Save**.

The following items are available:

- **U-Turns**: Avoids u-turns.
- **Motorways**: Avoids motorways.
- **Toll and Fees**: Avoids toll roads.
- **Ferries**: Avoids ferries.
- **Car Share Lanes:** Avoids car share lanes.
- **Unpaved Roads**: Avoids unpaved roads.

Avoidances

Motorways, **Toll and Fees** and **Ferries** are set to off as factory default.

Custom Avoidances

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Custom Avoidances

Allows you to avoid specific areas and sections of road. You can enable and disable custom avoidances as needed.

Select an option.
▶ Select **Add New Custom Avoidance** if custom avoidances are already stored.

The following options are available:

- **Add Avoid Area**: Sets an avoid area.
  Adding an Avoid Area P. 40
- **Add Avoid Road**: Sets an avoid road.
  Adding an Avoid Road P. 41

Continued

■Adding an Avoid Area

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Custom Avoidances ▶ Add Avoid Area



1. Select the upper-left (right) corner of the area to avoid. Select **Next**.
▶ The icon is displayed on the map.



2. Select the lower-right (left) corner of the area to avoid. Select **Next**.
▶ The selected area is shaded on the map.



3. Select **Done**.

Adding an Avoid Road

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Custom Avoidances ▶ Add Avoid Road



1. Select the starting point of the section of road to avoid. Select **Next**.
▶ The icon is displayed on the map.

Continued



2. Select the ending point of the road section. Select **Next**.



3. Select **Done**.

Editing a Custom Avoidance

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Custom Avoidances



1. Select the area or road to edit from the list.

2. Select ☰.
▶ The menu screen is displayed.

3. Select an item.

The following items are available:

- **Rename**: Enters a new name.
- **Delete**: Deletes a selected area or road.
- **Disable**: Disables the avoidance.

Continued

■ Deleting Custom Avoidances

HOME ▶ Navigation ▶ Settings ▶ Navigation ▶ Custom Avoidances



1. Select .



2. Select items you want to delete.
▶ Select **Select All** for all items in the list.

3. Select **Delete**.

HOME ▶ Navigation ▶ Settings ▶ Traffic



Select an item.

The following items are available:

- **Traffic**: Enables the traffic feature.
- **Current Provider**: Sets the traffic provider to use for traffic data.
- **Subscriptions**: Display the lists of the current traffic subscriptions.
- **Optimise Route**: Sets whether to use Optimised routes **On Request** or **Automatic**.
  On Request: Changes the route when receiving the traffic information.
  Automatic: Automatically optimises the route when receiving the traffic information.

Units & Time

HOME ▶ Navigation ▶ Settings ▶ Units & Time

Set the time format and adjust the current time for navigation screen. You can also set the map units.



Select an item.

The following items are available:

- **Current Time**: Sets the device time.
  Current P. 47
- **Time Format**: Allows you to select a 12-hour, 24-hour, or UTC display time.
  Time Format P. 47
- **Units**: Sets the unit of measure used for distances.
  Units P. 48

Current

HOME ▶ Navigation ▶ Settings ▶ Units & Time ▶ Current Time

Flick to adjust the current time.

Time Format

HOME ▶ Navigation ▶ Settings ▶ Units & Time ▶ Time Format



1. Select an item.
2. Select **Save**.

The following items are available:

- **24-Hour**: Displays the 24 hour clock.
- **12-Hour**: Displays the 12 hour clock.
- **UTC**: Displays UTC (Coordinate Universal Time) time.

Current

Automatic
Sets the time automatically when your navigation system is receiving satellite signals. Factory default is on.

Continued

Units

HOME ▶ Navigation ▶ Settings ▶ Units & Time ▶ Units



1. Select an item.
2. Select **Save**.

The following items are available:

- **Miles**: Sets the units to miles.
- **Kilometres**: Sets the units to kilometres.

Language & Keyboard

HOME ▶ Navigation ▶ Settings ▶ Language & Keyboard

Set the language for the unit and the keyboard layout.

Select an item.

The following items are available:

- Voice Language: Sets the language for voice prompts.
  Voice Language P. 50
- Keyboard Language: Sets the language for your keyboard.
  Keyboard Language P. 50
- Keyboard Layout: Sets the keyboard layout.
  Keyboard Layout P. 51

Language & Keyboard

When you select a language for the system, the language setting of the navigation app is automatically switched.
See the Owner's Manual for instructions.

Continued

Voice Language

HOME ▶ Navigation ▶ Settings ▶ Language & Keyboard ▶ Voice Language

1. Select the language from the list.
2. Select **Save**.

Keyboard Language

HOME ▶ Navigation ▶ Settings ▶ Language & Keyboard ▶ Keyboard Language

1. Select the language from the list.
2. Select **Save**.

Keyboard Layout

HOME ▶ Navigation ▶ Settings ▶ Language & Keyboard ▶ Keyboard Layout



1. Select an option.
2. Select **Save**.

The following options are available:

- **QWERTY** (factory default): Sets the keyboard layout to QWERTY.
- **ABCDE**: Sets the keyboard layout to ABCDE.

Device

HOME ▶ Navigation ▶ Settings ▶ Device



Select an option.

The following options are available:

- About: Displays the device information.
  About P. 53
- Travel History: Allows the device to record information for suggested routes, previous routes and destinations, and Trip Log features.
- Clear Travel History: Deletes the recorded information.
- Update Map: Displays the description screen of map updates.
  Obtaining a Navigation Update P. 129

About

HOME ▶ Navigation ▶ Settings ▶ Device ▶ About

Displays the device information.

Reset Factory Default Settings

HOME ▶ Navigation ▶ Settings ▶ ☰

You can restore all settings to the factory default values.



1. Select **Restore**.
2. Select **Yes**.

Reset Factory Default Settings

If you want the navigation app set to the factory default, select the **Factory Data Reset** of the system. For more details, see the Owner's Manual.

When you select ☰ in each settings category, you can restore the selected category.

Navigation

This section describes how to enter a destination, select a route to take, and follow the route to your destination. It also describes how to change your route or destination along the way.

Entering a Destination 56
HONDA 59
Address 60
Categories 65
Favourites 70
History 70
Map Input 71
Calculating the Route 72
Viewing the Routes 73
Viewing the Destination Map 74
Driving to Your Destination 75
Viewing the Route 75
Map Operation 79
Map Menu 80
Traffic Information (For applicable countries) 84
Changing Your Route 88
Stopping the Route 88
Taking a Detour 89
Adding Waypoints 90
Editing the Destination List 91
Changing Your Destination 95
Selecting a Destination on the Map 95
Searching Near Establishment 96
Entering a New Destination 98
Entering a New Destination from Trip Planner 99

HOME ▶ Navigation ▶ Where To?

This section describes how to enter a destination for route guidance.

Select an item.

The following items are available:

- Enter Search: Sets a destination by entering a category, brand name, address, or town name.
  Using the Search Bar P. 57
- Searching Near: Sets by selecting search area.
  Changing the Search Area P. 58
- Go Home: Sets your home address as a destination.
  Going Home P. 8
- HONDA: Sets a destination by entering a Honda dealer.
- Address: Sets a destination by entering an address.
  Address P. 60
- Categories: Sets a destination by selecting a category.
  Categories P. 65
- Favourites: Sets a destination by selecting a place stored in the Favourites list.
  Favourites P. 70
- History: Sets a destination by selecting a previous destination.
  History P. 70

- **Personalise**: Adds shortcuts to **Where To?** menu.
  Adding Shortcuts P. 59

Using the Search Bar

HOME ▶ Navigation ▶ Where To? ▶ Enter Search

You can use the search bar to search for locations by entering a category, brand name, address, or town name.

1. Enter a search term.
   ▶ Suggested search terms appear below the search bar as you type.
2. Select or suggested search term.



3. Select your destination from the list.
4. Set the route to your destination.
   Calculating the Route P. 72

Using the Search Bar

- To search for a type of business, enter a category name, such as "movie theaters."
- To search for a business by name, enter all or part of the name.
- To search for an address near you, enter the street number and street name.
- To search for an address in another town, enter the street number, street name, town, and state.
- To search for a town, enter the town and state.

Continued

Changing the Search Area

HOME ▶ Navigation ▶ Where To? ▶ Searching Near

By default, your device finds locations closest to your current location. You can find a location near another town or location.



Select an item.

The following items are available:

- **Where I Am Now**: Searches near your current location.
- **My Current Route**: Searches along your current route.
- **My Destination**: Searches near your current destination.
- **A Different Town**: Searches near the town you enter.
- **A Recent Destination**: Searches near a recent destination.
- **A Favourite Destination**: Searches near a favourite place.

Changing the Search Area

My Current Route and **My Destination** can be set when the route is active.

■ Adding Shortcuts

HOME ▶ Navigation ▶ Where To? ▶ Personalise

Up to 36 shortcut icons can be stored.



Select an item you want to add a shortcut.

HONDA

HOME ▶ Navigation ▶ Where To? ▶ HONDA

Find any HONDA services for a destination.



1. Select the desired name from the list.
2. Set the route to your destination.
   Calculating the Route P. 72

Adding Shortcuts

You can delete unwanted shortcuts.
Deleting Shortcuts P. 19

Address

HOME ▶ Navigation ▶ Where To? ▶ Address

Enter an address to use as the destination. The country you are currently in is displayed (e.g., United Kingdom).

Select an item.

The following items are available:

- Spell Town: Selects your destination town.
  Selecting the Town P. 63
- Spell Post Code: Selects your destination post code.
  Selecting the Post Code P. 64
- Search All: Sets an address to use as the destination.
  Search All P. 62
- Change Country: Selects the country.
  Selecting the Country P. 61

■ Selecting the Country

HOME ▶ Navigation ▶ Where To? ▶ Address ▶ Change Country



1. Enter a Country name.

2. Select a Country from the list.

Continued

■Search All

HOME ▶ Navigation ▶ Where To? ▶ Address ▶ Search All

1. Enter the house number. Select **Done**.
2. Enter the street name. Select **Done**.

3. Select your destination street from the list.
   ▶ If the select Town screen is displayed, select a town.
4. Set the route to your destination.
   Calculating the Route P. 72

Search All

The order of the steps may change depending on the map data loaded on your device.

Selecting the Town

HOME ▶ Navigation ▶ Where To? ▶ Address ▶ Spell Town



1. Enter the name of a different town. Select **Done**.
▶ A list of matching hits is automatically displayed after you enter several letters, with the closest match at the top of the list.

2. Select your destination town from the list.
▶ Next, you are prompted to enter a house number.
Search All P. 62

Selecting the Town

Vehicle position may not be displayed when:
- The automobile is travelling off-road.
- The vehicle position data cannot be updated.

You do not need to enter spaces or symbols (e.g., &, -, %).

The order of the steps may change depending on the map data loaded on your device.

Continued

■Selecting the Post Code

HOME ▶ Navigation ▶ Where To? ▶ Address ▶ Spell Postal Code

1. Enter the postal code. Select **Done**.
2. Select your destination postal code from the list.
3. Enter the house number. Select **Done**.
4. Enter the street name. Select **Done**.
5. Select your destination street from the list.

Calculating the Route P. 72

Selecting the Post Code

The order of the steps may change depending on the map data loaded on your device.

Categories

Select the category of a place (e.g., Restaurants, Petrol Stations, Shopping) stored in the map database to search for the destination.

Finding a Location by Category

HOME ▶ Navigation ▶ Where To? ▶ Categories



1. Select a category.



2. Select a subcategory.
▶ If subcategory screen is not displayed, proceed to step 3.

Categories

This option is convenient if you do not know the exact name of a place or if you want to narrow down the number of matches returned for places with a common name.

When you set the destination or waypoint, the same categories of icons do not appear.

Quick Search screen
After you have performed a search for a destination, certain categories display a **Quick Search** list that display the four destinations you selected.



Continued



3. Select a place name from the list.
4. Set the route to your destination.
Calculating the Route P. 72

Finding a Location by Junctions

HOME ▶ Navigation ▶ Where To? ▶ Categories ▶ Junctions

Select the intersection of two streets as the destination.

1. Select **Spell Town**.
▶ If select **Search All**, proceed to step 3.
▶ Select **Change Country**, if necessary.
Selecting the Country P. 61

2. Enter a town name. Select **Done**.
▶ A list of matching hits is automatically displayed after you enter several letters, with the closest match at the top of the list.
3. Select a town.

Finding a Location by Junctions

If there is more than one junction, you are prompted to select the junction. If the two streets that you have selected do not intersect, no junction is entered.

Continued

4. Enter the street 1 name. Select **Done**.
▶ A list of matching hits is automatically displayed after you enter several letters, with the closest match at the top of the list.
5. Select the street from the list.
▶ Repeat step 4 to search the second street.
6. Select the intersection.
7. Set the route to your destination.
➔ **Calculating the Route** P. 72

■ Finding a Towns

HOME ▶ Navigation ▶ Where To? ▶ Categories ▶ Towns

Selects your destination town centre.



1. Select a town.
▶ Select **Enter Search** and enter a town name if you want to narrow down the number of matches.
2. Set the route to your destination.
➔ **Calculating the Route** P. 72

Finding a Location Using Coordinates

HOME ▶ Navigation ▶ Where To? ▶ Categories ▶ Coordinates

You can find a location using latitude and longitude coordinates. This can be helpful when geocaching.



1. Select the latitude coordinate.
2. Enter the new coordinate. Select **Done**.
3. Select the longitude coordinate.
4. Enter the new coordinate. Select **Done**.
5. Select **View on Map**.
6. Set the route to your destination.

Viewing the Destination Map
P. 74

Finding a Location Using Coordinates

If you want to change the coordinate format, select ☰ and then select **Format**.

Favourites

HOME ▶ Navigation ▶ Where To? ▶ Favourites

Select a saved location to use as the destination.

1. Select your destination from the list.
2. Set the route to your destination.
   Calculating the Route P. 72

Favourites

If you want to delete all saved locations, select ☰ and then select **Delete Favourite(s)**.

History

HOME ▶ Navigation ▶ Where To? ▶ History

Select an address from a list of your 50 most recent destinations to use as the destination. The list is displayed with the most recent destination at the top.



1. Select your destination from the list.
2. Set the route to your destination.
   Calculating the Route P. 72

History

If you want to delete all recent destinations, select ☰ and then select **Clear**.

Map Input

HOME ▶ Navigation ▶ View Map

Scroll the map to manually select an icon or a location as the destination.



1. Select any point on the map.
2. Scroll a map, and select a street, intersection, or category icon you want to set a destination.
   ▶ Return to the current location when you select .
3. Set the route to your destination.
   Calculating the Route P. 72

Map Input

You can customize the map as you like using , , , or .
Map Operation P. 79

If you want to display a specific category of places, select and then select a category icon.

The place information is displayed when you select the on the map.
Viewing the Destination Map P. 74

This section describes how to calculate your route.



The following items are available:

- **Routes**: Displays different routes.
  Viewing the Routes P. 73
- : Display your destination map.
  Viewing the Destination Map P. 74

Select **Go!**.

▶ The system calculates and displays the route line on the map screen.

Calculating the Route

If the system has many guidance points on the route to the destination, it may stop at 99% calculation. In this case, the route guidance will start when you select **OK**.

Viewing the Routes

View different routes to your destination.



1. Select ◄ or ► to change a route.
▶ The travel distance, estimated travel time and traffic information are displayed for each route.
2. Select **Go!**.
▶ The system calculates and displays the route line on the map screen.

Viewing the Destination Map

1. Select an item.
2. Select **Go!**.
▶ The system calculates and displays the route line on the map screen.

The following items are available:

- Route Info: Displays different routes.
  Viewing the Routes P. 73
- Set Location: Sets the vehicle position when you are indoors or not receiving satellite signals.

Viewing the Destination Map

Select ☰ to display the following option:

Save

You can add the destination address to the saved location list.

Favourites Locations P. 20

Viewing the Route

This section describes how to follow the route guidance to your destination.

Map Screen



After calculating the route to your destination, the route is displayed on the map screen.

➡ **During Route Guidance** P. 7

As you drive, the system tracks your position on the map in real time and provides guidance as you approach each guidance point on the route.

The following items are available:

- Select the text bar on the top of the map to display the turn list screen.
  ➡ **Turn List** P. 76
- Select the Next guidance indicator to display the turn information screen or junction view screen (Junction view is for applicable countries only).
  ➡ **Turn Information** P. 77
- Select ⊗ to cancel the route guidance and remove your current route.
  ➡ **Canceling Your Route** P. 10
- Select ☰ to display the map menu.
  ➡ **Map Menu** P. 80
- Select Ⓟ to display the parking information screen of nearby parking.

» Viewing the Route

When connected via a *Bluetooth*® HandsFreeTelephone, the navigation app screen will switch to the incoming screen when receiving a call.

Speed limit icon

The speed limit shown on the map may be different from the actual speed limit and Traffic Sign Recognition System*.

For more details about Traffic Sign Recognition System, see the owner's manual.

Select the vehicle icon to view the **Where Am I?** screen.

➡ **Viewing the Current Location Information** P. 82

The system clock and navigation app clock are based on different conditions.

Therefore, the system clock and navigation app clock will not match when crossing a time zone and during summertime.

For details on system clock adjustment, see the owner's manual.

You can stop your vehicle en route (e.g., to rest, stop for gas, etc.), and then continue on your route.

If you did not complete your route, the navigation restarts when you restart your vehicle.

Continued

* Not available on all models

- Select the arrival time in the lower left to change the information displayed. Select the following options:
  Estimated Time of Arrival, **Distance to Destination**, **Estimated Time to Destination**, **Via Arrival**, **Distance to Via**, **Time to Via**, **Direction of Travel**, **Elevation** or **Time of Day**.

■ Turn List

The turn list screen displays turn-by-turn instructions and the distance between turns.



Select the text bar on the top of the map.

▶ Select a turn to display the detailed information.
Turn Information P. 77

▶ Select ☰ to display the entire route on the map.
Entire Route P. 77

Viewing the Route

The next guidance indicator does not appear in the following cases.
- The vehicle speed is 3 mph (4.8 km/h) or less
- The GPS signal is weak
- The vehicle position on the map and current vehicle position do not match

The system displays a roundabout to the next guidance indicator in the following cases.
- Its diameter is 82 ft (25 m) or more
- There is no road inside it
- There is no stop sign

Junction View Screen (For applicable countries)
The junction view screen displays a view of the upcoming junction and which lane you should be driving.

■Turn Information

The turn information screen displays the turn on the map and the distance and time left before you reach the turn. For applicable countries, the lane assist screen may display a view of the upcoming junction.

Select the upper-left corner of the map or select any turn on the turn list screen.

■Entire Route

The entire route screen displays the entire route, destination name, time to destination, and distance to destination.



1. Select the text bar on the top of the map.
2. Select ☰.
3. Select **Map** to display the entire route screen.
   ▶ Select ↩ to return to the previous screen.

Entire Route

You can customize the map as you like using +, −, ▲ or ↻.

Map Operation P. 79

Continued

■ Deviating From the Planned Route

If you leave the calculated route, the system automatically recalculates a route to the desired destination based on your current location and direction.

■ Trip Log Display

If you set the trip log to show, a series of dots (breadcrumbs) is displayed to track the path you are taking.

Map Layers P. 34



Trip Log Display

You can delete the Trip Log.

Device P. 52
Reset Factory Default Settings P. 54

Customize the map as you like. You can also set a destination and save a place from the map.



1. Select any point on the map.
2. Select an option.
▶ If you want to set a destination or to save a favourite in the map, scroll the map and select the desired location.
➔ **Favourites Locations** P. 20
➔ **Map Input** P. 71

The following options are available:

- : Zooms in the map.
- : Zooms out the map.
- : Switches the map to 2D or 3D.
- : Rotates the 3D map in anticlockwise direction.
- : Sets the data that appears on the map.
  ➔ **Map Layers** P. 34

Map Operation

When you select **Track Up** or **North Up**, the current map scale and the (Track Up only) appear on the map.
The always points North.
➔ **Driving Map View (Map Orientation)** P. 30

Map Menu

HOME ▶ Navigation ▶ View Map ▶ ☰

Select an item.

The following options are available:

- **Mute**: Turns the voice prompts on or off.
- **Stop**: Cancels the route guidance and removes your current route.
- **Detour**: Calculates a detour route.
  ➔ **Taking a Detour** P. 89
- **Exit Services**: Displays a list of the exit services for the route.
  ➔ **Viewing Exit Services** P. 81
- **Where Am I?**: Displays the information about your current location.
  ➔ **Viewing the Current Location Information** P. 82
- **Map Layers**: Sets the data that appears on the map.
  ➔ **Map Layers** P. 34
- **Where To?**: Enter a new destination using the destination menu even when en route.
  ➔ **Entering a Destination** P. 56
- **ecoRoute™**: Uses the ecoRoute™ features.
  ➔ **ecoRoute™** P. 105

Viewing Exit Services

HOME ▶ Navigation ▶ View Map ▶ ☰ ▶ Exit Services

You can view exit services (e.g., whether the exit is near fuel stations, restaurants, etc.) and add new destinations or waypoints to the calculated route.



1. Select ◀ or ▶ to display your desired list of exit services.
2. Select a category tab.
3. Select an item.
   ▶ The location is displayed on the Calculate Route screen.
   Viewing the Destination Map P. 74

Viewing Exit Services

The map screen of the selected exit is displayed when you select .

Continued

■Viewing the Current Location Information

HOME ▶ Navigation ▶ View Map ▶ ☰ ▶ Where Am I?

You can confirm your current location, address, and nearest intersection.



Select an item.

The following options are available:

- **Save**: Saves your current location.
  Saving Your Current Location P. 21
- **Hospitals/Police Stations/Fuel**: Search for a hospital, police station, or fuel station around your current location.
  Searching Near Establishment P. 96

Using Direction to Me

HOME ▶ Navigation ▶ View Map ▶ ☰ ▶ Where Am I?

If you need to tell another person how to get to your current location, your device can give you a list of directions.

1. Select ☰.
2. Select **Directions to Me**.
3. Select an item.
4. Select **Select**.
   ▶ The turn list screen displays turn-by-turn instructions and the distance between turns.
   Turn List P. 76

Traffic Information (For applicable countries)

When calculating your route, the device examines the current traffic and automatically optimises the route for the shortest time. If a severe traffic delay occurs on your route while you are navigating, your device automatically recalculates the route.

The traffic icon changes colour to indicate the severity of traffic conditions on your route or on the road you are currently travelling. Your device may route you through a traffic delay if a better alternative route does not exist. The delay time is added into your estimated time of arrival automatically.

1. Select on the map screen.

2. Select an item.

The following options are available:

- Traffic on Route: Displays the traffic delays on your route. You can select the traffic you want to avoid.
  ➔ **Traffic Rerouting Manually** P. 85
- Traffic Conditions: Displays a list of traffic delays.
  ➔ **Viewing Traffic Delays** P. 86
- Traffic Legend: Displays an overview of traffic legends.
  ➔ **Viewing Traffic Legends** P. 87

Traffic Information (For applicable countries)

The traffic icon changes colour to indicate the severity of traffic conditions.

- **Green:** Flowing freely.
- **Yellow:** Moderate traffic condition.
- **Red:** Very slow or stop-and-go traffic.
- **Gray:** No traffic data.

Alternate Route

1. Select while navigating an automobile route.

2. Select Alternate Route.

3. Select a route.

■Traffic Rerouting Manually

HOME ▶ Navigation ▶ View Map ▶ ▶ Traffic on Route

View the traffic delays on your route, including the estimated time of each delay and the distance to each delay. You can select the traffic you want to avoid manually.
Select ☰ and then select **Avoid** to avoid the traffic delay.
▶ Select ◀ or ▶ to view other traffic delays on your route.

Continued

■Viewing Traffic Delays

HOME ▶ Navigation ▶ View Map ▶ ▶ Traffic Conditions

View a list of traffic delays.

1. Select an item in the list to view the delay on a map.

2. Select ◄ or ► to change the information if there is more than one delay.

■ Viewing Traffic Legends

HOME ▶ Navigation ▶ View Map ▶ ▶ Traffic Legend

See an overview of the icons and colours used on the traffic map.
▶ The system displays the traffic legend.

Stopping the Route

HOME ▶ **Navigation** ▶ **View Map** ▶ (when en route)

Stop the route guidance and remove the destination and all waypoints from the destination list.



Stopping the Route

You can also stop your route from the map menu.
Map Menu P. 80

Taking a Detour

HOME ▶ Navigation ▶ View Map ▶ ☰ ▶ Detour (when en route)

Calculate a new route to avoid something ahead of you. The system creates a new route, if possible. The system attempts to get you back on your original route as quickly as possible.

Taking a Detour Around Specified Areas

You can take a detour for a specified distance along your route or detour around specific roads. This is useful if you encounter construction zones, closed roads, or poor road conditions.



Select an item.

Taking a Detour

If your current route is the only reasonable option, the system might not calculate a detour.

Taking a Detour Around Specified Areas

You can use this feature when **Advanced Detours** is set to On.

Navigation P. 36

Select 🗑 to delete all detours.

Adding Waypoints

Add waypoints (pit stops) along the route to your destination.





1. Select a search method to add a waypoint.
   - **Entering a Destination** P. 56
2. Select a place. Select **Go!**.
3. Select **Add to Active Route**.
   - ▶ Select **Start New Route** to set the location as your new destination.
     - **Entering a New Destination** P. 98
4. Select ≡ and move the order of destinations.
5. Select **Done**.
   - ▶ The route is automatically recalculated and displayed on the map screen.

Adding Waypoints

When you add a waypoint, the system may take some time to update the arrival time.

Editing the Destination List

Editing Places on the Your Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner (when en route) **▶ Unsaved Trip**

1. Select a place from the destination list.



2. Select an item.

The following options are available:

- **Departure Time** (current location only): Sets the departure time.
- **Clear Departure Time** (current location only): Clears the departure time.
- **Arrival Time** (destination and waypoints): Sets the arrival time.
- **Clear Arrival Time** (destination and waypoints): Clears the arrival time.
- **Duration** (destination and waypoints): Sets the duration time.
- **Change Location**: Changes the destination or waypoints.

Continued

Editing the Destination List

Select **Map** to display the destination and waypoints on the map screen.

Reorder Your Destination List Automatically P. 93

- **Remove Location**: Removes the destination or waypoints.
- **Rename Location**: Enters a new name for the location.

Editing Your Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner (when en route) **▶ Unsaved Trip ▶ ☰ ▶ Edit Destinations**

1. Select ☰ and move the order of destinations.
   ▶ Select ✚ to add a new location.
   ▶ Select 🗑 to delete destinations from the destination list.
2. Select **Save**.
   ▶ The route is automatically recalculated.

Saving Your Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner (when en route) **▶ Unsaved Trip ▶ ☰ ▶ Save Trip**

1. Enter a route name.
2. Select **Done**.

Reorder Your Destination List Automatically

HOME ▶ Navigation ▶ Apps ▶ Trip Planner (when en route) **▶ Unsaved Trip ▶ ☰ ▶ Optimise Order**

Automatically order the waypoints in the destination list.

Select **Map** to display the destination and waypoints on the map screen.

Reorder Your Destination List Automatically

Select ☰, and then select **Review Trip** to display the turn list.

Turn List P. 76

Continued

■ Recalculate Using Another Route Preference

HOME ▶ Navigation ▶ Apps ▶ Trip Planner (when en route) **▶ Unsaved Trip ▶ ☰ ▶ Route Preference**

The route preference is just for this time. If you want to change the route preference for routing, change the navigation settings.

Calculation Mode P. 37

Recalculates the route using another route preference.



1. Select an item.
2. Select **Save**.
▶ The route is automatically recalculated.

Selecting a Destination on the Map

Select a new destination when en route by selecting a location on the map.



1. Select any point on the map.
2. Scroll a map, and select a street, intersection, or category icon you want to set a destination.
3. Select **Go!**.



4. Select an item.

The following options are available:

- **Start New Route**: Sets the location as your new destination.
- **Add to Active Route**: Sets the location as the first waypoint.

Adding Waypoints P. 90

Searching Near Establishment

HOME ▶ Navigation ▶ View Map ▶ ▶ Where Am I?

Search for a hospital, police station, or fuel station around your current location.



1. Select a category type.
▶ You can also confirm your current location, address, and nearest intersection.



2. Select a place.
3. Select **Go!**.

4. Select an item.

The following options are available:

- **Start New Route**: Sets the location as your new destination.
- **Add to Active Route**: Sets the location as the first waypoint.

Adding Waypoints P. 90

Entering a New Destination

HOME ▶ Navigation ▶ Where To?

Enter a new destination using the Destination menu screen even when you are en route.

1. Select a search method to enter a new destination.
➡ **Entering a Destination** P. 56



2. Select a place and then Select **Go!**.
3. Select an item.

The following options are available:

- **Start New Route**: Sets the location as your new destination.
- **Add to Active Route**: Sets the location as the first waypoint.
➡ **Adding Waypoints** P. 90

Entering a New Destination from Trip Planner

You can use the trip planner to create and save a route with multiple destinations.

■ Creating Your Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner ▶ New Trip ▶ Select Start Location

1. Select a method to enter a new destination.
Entering a Destination P. 56
2. Select **Select**.



3. Select ✚ to add additional locations.
▶ Repeat step 1 and 2 to search the destination.
▶ Select ☰ and move the order of destinations.
▶ Select 🗑 to delete unwanted destinations.
4. Select **Next**.

Continued

5. Enter a route name.
6. Select **Done**.

7. Select **Go!**.
► Select **Map** to display the destination and waypoints on the map screen.
Reorder Your Destination List Automatically P. 93



8. Select next destination from the list.
9. Select **Start**.
► The route is automatically recalculated and displayed on the map screen.

Creating Your Route

Select ☰ to display the **Edit Trip** screen.
Editing the Saved Route P. 101

Using the Saved Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner



1. Select a saved route.
2. Select **Go!**.
3. Select next destination from the list.
4. Select **Start**.
   ▶ The route is automatically recalculated and displayed on the map screen.

Editing the Saved Route

HOME ▶ Navigation ▶ Apps ▶ Trip Planner



1. Select a saved route you want to edit.
2. Select ☰.

Continued



3. Select an item.

The following options are available:

- Edit Destinations: Edits the destination list of the saved trip.
  ➡ **Editing Your Route** P. 92
- Delete Trip: Deletes a saved trip.
- Rename Trip: Enters a new name for the saved trip.
- Optimise Order: Automatically order the waypoints in the destination list.
  ➡ **Reorder Your Destination List Automatically** P. 93
- Route Preference: Changes the route preferences (calculating method).
  ➡ **Recalculate Using Another Route Preference** P. 94

Other Features

This section describes the useful functions incorporated into the navigation app.



About Apps Menu 104
ecoRoute™ 105
Setting Up the Vehicle Profile 106
Viewing the Vehicle Profile 108
Calibrating the Fuel Economy 109
Viewing the ecoChallenge Scores 110
Viewing Fuel Economy Information 111
Viewing a Mileage Report 112
Information Functions 113
Help 113
Where I've Been 114
Calculator 115
Unit Converter 116
GPS Information 117

HOME ▶ Navigation ▶ Apps

Display the useful functions incorporated into the navigation app.

Select an item.

The following items are available:

- **Help**: Display the Help function.
  Help P. 113
- **ecoRoute™**: Displays fuel economy information, mileage report, your driving habit and vehicle information.
  ecoRoute™ P. 105
- **Trip Planner**: Sets the trip planner to create and save a trip with multiple destinations.
  Editing the Destination List P. 91
  Entering a New Destination from Trip Planner P. 99
- **Where I've Been**: Display your previous routes and places you have stopped on the map.
  Where I've Been P. 114
- **Calculator**: Display the Calculator function.
  Calculator P. 115
- **Unit Converter**: Display the Unit Converter function.
  Unit Converter P. 116

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™

The ecoRoute™ feature calculates the fuel economy and the fuel price of navigating to a destination, and offers tools for improving fuel efficiency.
The data provided by the ecoRoute feature is an estimate only.
To receive more-accurate fuel reports for your specific vehicle and driving habits, calibrate the fuel economy.

Select an item.

The following items are available:

- At The Pump: Calibrates the fuel economy to receive more-accurate fuel reports.
  Calibrating the Fuel Economy P. 109
- ecoChallenge: Helps you maximize the vehicle fuel economy by scoring your driving habits.
  Viewing the ecoChallenge Scores P. 110
- Fuel Economy: Displays fuel economy information.
  Viewing Fuel Economy Information P. 111
- Vehicle Profile: Check or reset your vehicle information.
  Viewing the Vehicle Profile P. 108
- Mileage Report: Displays mileage reports for your vehicle.
  Viewing a Mileage Report P. 112

Setting Up the Vehicle Profile

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™

The first time you use the ecoRoute features, you must enter vehicle information.



1. Select **Yes**.



2. Select a fuel type.
3. Select **Next**.

4. Enter the fuel information of cities.
5. Select **Next**.

6. Enter the fuel information of motorways.
7. Select **Next**.



8. Enter the fuel price.
9. Select **Next**.
▶ The confirmation message will appear.
10. Select **OK**.

Viewing the Vehicle Profile

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™

Select **Vehicle Profile**.

▶ If you reset the **Vehicle Profile**, select **Reset**.

Calibrating the Fuel Economy

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™ ▶ At the Pump

You can calibrate the fuel economy to receive more-accurate fuel reports for your specific vehicle and driving habits. You should calibrate when you fill up your fuel tank.





1. Enter the current fuel price.
2. Enter the amount of fuel the vehicle has used since the last time the fuel tank was filled.
3. Enter the distance you have travelled since the last time the fuel tank was filled.
4. Select **Next**.
   ▶ The device calculates the average vehicle fuel economy.
5. Select **Save**.

Viewing the ecoChallenge Scores

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™ ▶ ecoChallenge

The ecoChallenge feature helps you maximize the vehicle fuel economy by scoring your driving habits. The higher your ecoChallenge scores, the more fuel you have saved. The ecoChallenge collects data and calculates a score whenever your device is moving and in Automobile transportation mode.

The following information is displayed:

- **Current**: Displays the score for your current driving activity.
- **Overall**: Displays an average of the speed, acceleration, and braking score.
- **Speed**: Displays your score for driving your vehicle at the optimal speed for conserving fuel (45–60 mph for most vehicles).
- **Acceleration**: Displays your score for smooth and gradual acceleration. You lose points for rapid acceleration.
- **Braking**: Displays your score for smooth and gradual braking. You lose points for hard braking.

Viewing the ecoChallenge Scores

If you reset the **ecoChallenge** Scores, select ☰ and then select **Reset**.

Viewing Fuel Economy Information

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™ ▶ Fuel Economy

You can view your fuel consumption, your total fuel cost, and your average fuel economy.

Select a section of the graph to zoom in.

Viewing Fuel Economy Information

If you reset the **Fuel Economy** information, select and then select **Reset**.

Viewing a Mileage Report

HOME ▶ Navigation ▶ Apps ▶ ecoRoute™ ▶ Mileage Report

You can view saved mileage reports on the device.
Select a report.

Viewing a Mileage Report

Mileage Reports

Mileage reports provide the distance, the time, the average fuel economy, and the fuel cost of navigating to a destination.

A mileage report is created for every route that you drive. If you stop a route on the device, a mileage report is created for the distance you travelled.

Help

HOME ▶ Navigation ▶ Apps ▶ Help



Select a help topic you want to display.

Searching Help Topics

HOME ▶ Navigation ▶ Apps ▶ Help ▶



1. Enter a keyword. Select **Done**.

Help

You can also display the help topic to select on each menu screen.

Continued



2. Select a help topic you want to confirm.

Where I've Been

HOME ▶ Navigation ▶ Apps ▶ Where I've Been

Before you can use this feature, you must enable the travel history feature. You can view your previous routes and places you have stopped on the map.



Where I've Been

If you want to delete the recorded information, select ☰ and then select **Clear Travel History**.

Calculator

HOME ▶ Navigation ▶ Apps ▶ Calculator

Enter a numeric value to calculate.

Unit Converter

HOME ▶ Navigation ▶ Apps ▶ Unit Converter



1. If necessary, Select a measurement category (e.g., **Distance**).
▶ Select a measurement category from the list. Select **Save**.

2. If necessary, Select a unit of measurement (e.g., **km**).
▶ Select a unit of measurement from the list. Select **Save**.

3. Enter a numeric value to convert (e.g., 1000). Select **Done**.

GPS Information

HOME ▶ Navigation

The GPS info screen displays the satellites status.



Select and hold the .

▶ The picture on the left shows status of each GPS satellite.

▶ A solid bar indicates that the GPS satellite is ready for use.

Troubleshooting

Troubleshooting 120
Map, Voice, Entering Destinations 120
Traffic 121
Guidance, Routing 122
Update, Coverage, Map Errors 123
Display, Accessories 123
Miscellaneous Questions 124

Map, Voice, Entering Destinations

Problem	Solution
The Startup Confirmation screen is displayed every time I start the car.	This is normal. The Startup Confirmation screen reminds you and your guest drivers to always operate the navigation system in a safe manner. The Startup Confirmation screen goes off after a certain period of time, even if you do not select **OK**.
The navigation system reboots by itself (returns to the opening screen).	A reboot can be caused by extreme temperatures or shock from bumpy roads, and does not necessarily indicate a problem. If this happens frequently, please see your dealer.
How do I specify a destination when an entered town or street could not be found?	Try selecting the destination directly from the map. ➡ **Map Input** P. 71
How do I delete saved places, or the Home Address?	**1.** Press the **HOME** button. Select **Navigation** > **Where To?** > **Favourite(s)** > ☰ > **Delete Favourite(s)**. **2.** Select saved places you want to delete. **3.** Select **Delete**. **4.** Select **Yes**.
I cannot hear the navigation system voice.	**1.** Press the **HOME** button. Select **Navigation** > **Settings** > **Navigation** and set **Voice Prompt** to on. ➡ **Navigation** P. 36 **2.** Press the **HOME** button. Select **Settings** > **System** > **Sound/Beep** tab and check that **Volume** is not set to 0.

Traffic

Problem	Solution
Traffic information is missing or is not displaying properly. What is wrong?	Verify the following: • Traffic information relies on a clear signal. If signal strength is low, traffic data may not be available. • Check that the traffic icons are turned on. ➡ **Traffic Information (For applicable countries)** P. 84 • It is possible that there is a temporary technical problem with your metropolitan area traffic. You can call Honda Automobile Customer Service to see if there is an outage. ➡ **Honda Automobile Customer Service Contact Information** P. 129 • If the situation persists, see your Honda dealer for assistance. • Traffic information is available only in certain areas.

Guidance, Routing

Problem	Solution
The navigation system does not route me the same way I would go or the same way as other mapping systems.	The navigation system attempts to generate the optimal route. You can change the route preferences used when calculating a route. ➡ **Recalculate Using Another Route Preference** P. 94
The street I'm on is not shown on the map screen.	The mapping database is constantly undergoing revision. You can access the most recent information on the internet. ➡ **Map Coverage** P. 129
The vehicle position icon is not following the road.	• Check that the GPS antenna (located in the dashboard) is not blocked. For best reception, remove items from the dashboard, such as radar detectors, cellular phones, or loose articles. • Metallic tinting or other aftermarket devices can interfere with the GPS reception. Please consult your dealer. ➡ **GPS System** P. 127
How do I stop the map from rotating as I drive along?	**1.** Press the **HOME** button. Select **Navigation** > **Settings** > **Map & Vehicle** > **Driving Map View** and check that **Driving Map View** is set to **Track Up** or **3-D**. **2.** Select **North Up**. **3.** Select **Save**.
The "arrive time" display sometimes increases even though I am getting closer to my destination.	"Arrival time" is based on the speed limit on each road. Depending on the traffic conditions, the "arrival time" may be calculated to be earlier or later.
My elevation (shown when I display the current position) seems to fluctuate even though my elevation has not changed.	This is normal. The elevation can vary ±30 m due to GPS calculation errors. ➡ **GPS System** P. 127
My elevation is missing on the "current position" screen.	The elevation is only displayed if the GPS antenna can receive signals from at least four satellites. Try moving the vehicle into an open area. The elevation is also not displayed if the calculated elevation is zero or below sea level.

Update, Coverage, Map Errors

Problem	Solution
My town is not part of a fully verified detailed coverage area.	The mapping database is constantly undergoing revision. You can access the most recent information on the internet. ➔ **Map Coverage** P. 129
Does the navigation system work outside Europe?	The navigation system contains maps for Europe. The navigation system will not work in other countries. ➔ **Map Coverage** P. 129

Display, Accessories

Problem	Solution
The display appears dim when starting the car in really cold weather.	This is normal. The display will become brighter after a few minutes.

Miscellaneous Questions

Problem	Solution
My clock frequently changes forward and backward by one hour.	The clock setting is automatically updated based on your GPS location. ➡ **Units & Time** P. 46
My battery was disconnected or went dead, and the navigation system is asking for a code.	Press and hold the ⏻ (Audio Power) button for two seconds. The system should reactivate. If you have installed an aftermarket system, see your dealer. ➡ **Entering the Security Code** P. 126
How do I change the interface language?	Press the **HOME** button. Select **Settings** > **System** > **Language** and select the desired language for system language. See the owner's manual.

Reference Information

System Initialization 126
Entering the Security Code 126
Startup Confirmation Screen 126
System Limitations 127
GPS System 127
Address Calculation 127
Database 127
Customer Assistance 129
Resolving Problems 129
Honda Automobile Customer Service Contact Information 129
Visiting Your Dealer 129
Map Coverage 129
Obtaining a Navigation Update 129
Traffic Information 129
Legal Information 130
User Agreement 130

The navigation system must be initialized if power to the navigation system is interrupted for any reason (e.g., the battery was disconnected).

Entering the Security Code

You can find out about your serial number and security code from a dealer.



1. Turn the ignition switch* to ON, and turn on the system.
2. Press and hold the system power button for more than two seconds.
The system is reactivated when the system control unit establishes a connection with the vehicle control unit. If the control unit fails to recognise the system unit, you must go to a dealer and have the system unit checked.

* Models with the keyless access system have an **ENGINE START/STOP** button instead of an ignition switch.

Startup Confirmation Screen

The Startup Confirmation screen is displayed when initialization has successfully completed. It is displayed every time you start your vehicle. Select **OK** to continue.



GPS System

The signals received from the GPS satellites are extremely weak (less than a millionth of the strength of a local FM station) and require an unobstructed view of the sky. The GPS antenna is located in the dashboard. The signal reception can easily be interrupted or interfered with by the following:

- Metallic window tint on the front or side windows
- Cellular phones, PDAs, or other electronic devices docked in a cradle or lying loose on the dashboard
- Remote starters or "hidden" vehicle tracking systems mounted near the navigation unit
- Audio electronic devices mounted near the navigation unit
- Trees, tall buildings, motorway overpasses, tunnels, or overhead electrical power wires

The GPS is operated by the U.S. Department of Defense. For security reasons, there are certain inaccuracies built into the GPS for which the navigation system must constantly compensate. This can cause occasional positioning errors of up to several hundred feet (meters).

Address Calculation

The destination icon shows only the approximate location of a destination address. This occurs if the number of possible addresses is different from the number of actual addresses on a block. For example, the address 1425 on a 1400 block with 100 possible addresses (because it is followed by the 1500 block) will be shown a quarter of the way down the block by the system. If there are only 25 actual addresses on the block, the actual location of address 1425 would be at the end of the block.

Database

The digitized map database reflects conditions as they existed at various points in time before production. Accordingly, your database may contain inaccurate or incomplete data or information due to the passage of time, road construction, changing conditions, or other causes.

For example, some places/landmarks may be missing when you search the database because the name was misspelled, the place was improperly categorized, or a place/landmark is not yet in the database. This is also true for police stations, hospitals, and other public institutions. Do not rely on the navigation system if you need law enforcement or hospital services. Always check with local information sources.

Continued

The database does not include, analyze, process, consider, or reflect any of the following categories of information:

- Neighborhood quality or safety
- Population density
- Availability or proximity of law enforcement
- Emergency, rescue, medical, or other assistance
- Construction work, zones, or hazards
- Road and lane closures
- Legal restrictions (such as vehicular type, weight, load, height, and speed restrictions)
- Road slope or grade
- Bridge height, width, weight, or other limits
- Traffic facilities safety
- Special events
- Pavement characteristics or conditions

Every effort has been made to verify that the database is accurate. The number of inaccuracies you experience increases the longer you go without obtaining an updated map database.

➡ **Obtaining a Navigation Update** P. 129

We assume no liability for any incident that may result from an error in the program, or from changed conditions not noted above.

Resolving Problems

If you run into a specific issue that you cannot resolve, consult the following help resources:

- For navigation system issues:
  Troubleshooting P. 120
  Or, please contact your dealer.
- For traffic-related issues:
  Traffic P. 121
- For reporting issues with the database or places/landmarks.
- Call Honda Automobile Customer Service.

Honda Automobile Customer Service Contact Information

Please contact your dealer.

Visiting Your Dealer

If you have a question that you cannot resolve using the available help resources, you can consult your dealer. Please identify the specific issue (e.g., error occurs when you enter a specific address, when driving on a certain road, or just when it's cold) so that the service advisor can refer the issue to the factory so that a solution can be found. Be patient, the service advisor may be unfamiliar with your specific issue.

Map Coverage

The navigation system provides map coverage for the European region.

Obtaining a Navigation Update

Honda is continuously updating the navigation system.
Navigation system software is usually updated annually.
Please contact your Honda dealer for further information regarding the update program available for your vehicle.

Traffic Information

Continuously updated traffic information is available in major metropolitan areas.

User Agreement

END USER TERMS

The content provided ("Data") is licensed, not sold. By opening this package, or installing, copying, or otherwise using the Data, you agree to be bound by the terms of this agreement. If you do not agree to the terms of this agreement, you are not permitted to install, copy, use, resell or transfer the Data. If you wish to reject the terms of this agreement, and have not installed, copied, or used the Data, you must contact your retailer or HERE North America, LLC (as defined below) within thirty (30) days of purchase for a refund of your purchase price. To contact HERE, please visit *www.here.com*.

The Data is provided for your personal, internal use only and may not be resold. It is protected by copyright, and is subject to the following terms (this "End User License Agreement") and conditions which are agreed to by you, on the one hand, and HERE and its licensors (including their licensors and suppliers) on the other hand. For purposes of these terms, "HERE" shall mean (a) HERE North America, LLC with respect to Data for the Americas and/or the Asia Pacific region and (b) HERE Europe B.V. for Data for Europe, the Middle East and/or Africa.

The Data includes certain information and related content provided under license to HERE from third parties and is subject to the applicable supplier terms and copyright notices set forth at the following URL: *http://corporate.navteq.com/supplier_terms.html.*

TERMS AND CONDITIONS

License Limitations on Use: You agree that your license to use this Data is limited to and conditioned on use for solely personal, noncommercial purposes, and not for service bureau, timesharing or other similar purposes. Except as otherwise set forth herein, you agree not to otherwise reproduce, copy, modify, decompile, disassemble or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws.

License Limitations on Transfer: Your limited license does not allow transfer or resale of the Data, except on the condition that you may transfer the Data and all accompanying materials on a permanent basis if: (a) you retain no copies of the Data; (b) the recipient agrees to the terms of this End User License Agreement; and (c) you transfer the Data in the exact same form as you purchased it by physically transferring the original media (e.g., the CD-ROM or DVD you purchased), all original packaging, all Manuals and other documentation. Specifically, Multidisc sets may only be transferred or sold as a complete set as provided to you and not as a subset thereof.

Additional License Limitations: Except where you have been specifically licensed to do so by HERE in a separate written agreement, and without limiting the preceding paragraph, your license is conditioned on use of the Data as prescribed in this agreement, and you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles capable of vehicle navigation, positioning, dispatch,

real time route guidance, fleet management or similar applications; or (b) with, or in communication with, including without limitation, cellular phones, palmtop and handheld computers, pagers, and personal digital -assistants or PDAs.

Warning: This Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic Data, any of which may lead to incorrect results.

No Warranty: This Data is provided to you "as is", and you agree to use it at your own risk. HERE and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error free.

Disclaimer of Warranty: HERE AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: HERE AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THIS DATA; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS DATA, ANY DEFECT IN THIS DATA, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF HERE OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

Export Control: You agree not to export from anywhere any part of the Data or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations, including but not limited to the laws, rules and regulations administered by the Office of Foreign Assets Control of the U.S. Department of Commerce and the Bureau of Industry and Security of the U.S. Department of Commerce. To the extent that any such export laws, rules or regulations prohibit HERE from complying with any of its obligations hereunder to deliver or distribute Data, such failure shall be excused and shall not constitute a breach of this Agreement.

Continued

Entire Agreement: These terms and conditions constitute the entire agreement between HERE (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Severability: You and HERE agree that if any portion of this agreement is found illegal or unenforceable, that portion shall be severed and the remainder of the Agreement shall be given full force and effect.

Governing Law: The above terms and conditions shall be governed by the laws of the State of Illinois (for Data for the Americas and/or the Asia Pacific region) or The Netherlands (for Data for Europe, the Middle East and Africa), without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. For any and all disputes, claims and actions arising from or in connection with the Data ("Claims"), you agree to submit to the personal jurisdiction of (a) the State of Illinois for Claims related to Data for the Americas and/or the Asia Pacific region provided to you hereunder, and (b) The Netherlands for Data for Europe, the Middle East and/or Africa provided to you hereunder.

Government End Users: If the Data is being acquired by or on behalf of the United States government or any other entity seeking or applying rights similar to those customarily claimed by the United States government, this Data is a "commercial item" as that term is defined at 48 C.F.R. ("FAR") 2.101, is licensed in accordance with this End User License Agreement, and each copy of Data delivered or otherwise furnished shall be marked and embedded as appropriate with the following "Notice of Use", and be treated in accordance with such Notice:

NOTICE OF USE

CONTRACTOR (MANUFACTURER/ SUPPLIER) NAME:

HERE

CONTRACTOR (MANUFACTURER/ SUPPLIER) ADDRESS:

425 West Randolph Street, Chicago, IL 60606.

This Data is a commercial item as defined in FAR 2.101 and is subject to the End User License Agreement under which this Data was provided.
© 1987-2013 HERE. All rights reserved.

If the Contracting Officer, federal government agency, or any federal official refuses to use the legend provided herein, the Contracting Officer, federal government agency, or any federal official must notify HERE prior to seeking additional or alternative rights in the Data.

© 1987-2013 HERE. All rights reserved.

Symbols

(Display Mode) Button 3, 7, 26
(Power) Button 3

Numbers

3D Map 30

A

Adding Waypoints 90
Apps Menu 104
Avoidances 38

C

Calculating the Route 72
Calculation Mode 37
Cancel Route 10
Changing Your Destination 95
Changing Your Route 88
Custom Avoidances 39
Customer Assistance 129

D

Dashboards 34
Data Reset 54
Device 52
Display Mode 26
Driving to Your Destination 75

E

ecoRoute™ 105
Editing the Destination List 91
Entering a Destination 56
  Address 60
  Categories 65
  Favourites 70
  History 70
  HONDA 59
  Map Input 71
Entering a New Destination 98

F

Favourites 20
  Deleting 24, 25
  Editing 22
  Saving 20, 21

G

Go Home 8

H

Home 18
HOME Screen 3
Honda Customer Service 129

I

Information Functions 113

L

Language & Keyboard 49
Legal Information 130

M

Map & Vehicle 28
Map Buttons 33
Map Detail 31
Map Layers 34
Map Legend 6
Map Menu 80
Map Operation 79
Map Screen 75
  Icon 6
Map Theme 32
Map Update
  Obtaining Update Data 129
myMaps 35

N

Navigation 36
Navigation App 3
Navigation Menu Screen 3
North Up 30

O

Other Settings 46

P

Personal Information 17

S

Security Code 126
Setting
Data Reset 54
Device 52
Display Mode Settings 26
Language & Keyboard 49
Map & Vehicle 28
Navigation 36
Other Settings 46
Personal Information 17
Traffic 45
System Initialization 126
System Limitations 127

T

Track Up 30
Traffic 45
Indicator 6
Setting 45
Traffic Information 84
Troubleshooting 11, 120

U

Units & Time 46
Update System Software
Obtaining Update Data 129

V

Vehicle 29